





Emailing Data Files With iOS Version of Mantalink

In order to successfully email your data files when using an iOS device with the mantaLink App, an email account must be established through the native iOS Apple Settings.

1  To set up an email account for use with mantaLink, tap the **Settings** icon from your devices home screen.

2  Tap **Mail**.
Tap **Accounts**.
Tap **Add Account**.
Select **Account Type**. >



3 Follow the prompts to log in with email and password.

You are now ready to email your Snapshots, Log Files, and Calibration Log.

eureka™
water probes

waterprobes.com
support@waterprobes.com
2113 Wells Branch Pkwy
Austin, TX 78728
512-302-4333 ext. 1111