



Wireless mantaMobile Quickstart

Use the wireless mantaMobile to connect a Eureka probe to a Bluetooth-enabled mobile device and the mantaLink app.



- 1 Install mantaLink™ on your Android or iOS (Apple) device.
Note: For mantaLink Android on Google Play, do not select the Legacy version!
- 2 Connect a Eureka data cable or underwater cable to your multiprobe. Attach the cable to the mantaMobile via the 9-pin connector.
- 3 Press the power button to turn ON the mantaMobile. The blue circular status LED will blink, indicating Bluetooth is ready to pair. Solid green LEDs indicate battery status. 5 green LEDs indicates a full charge. Connect the mantaMobile charger and recharge if needed.
- 4 Launch the mantaLink App on your display device. The mantaLink HOME screen will open and you will see sensor data generated from your multiprobe. If the App does not auto-connect to your mantaMobile, press the CONNECT icon. Select the mantaMobile device from the AVAILABLE MANTAS list.
IMPORTANT: Do not attempt to pair through your device settings function as this can result in blocking a successful pairing. Only one mantaMobile at a time may be connected to your device.
- 5 For complete mantaLink operating instructions, visit our website, waterprobes.com. Click on the SUPPORT tab and select MANUALS. Download the PDF “MantaLink App with MantaMobile.” Please also visit our YouTube Channel for more instructional videos on mantaLink and other Eureka products at youtube.com/@eurekawaterprobes8632



Please email us or call with any questions!



eureka™
water probes

waterprobes.com
support@waterprobes.com
2113 Wells Branch Pkwy
Austin, TX 78728
512-302-4333 ext. 1111